



AURORA[®]

Photovoltaic Inverters

INSTALLATION AND OPERATOR'S MANUAL

Note: This document contains proprietary information of Power-One, Inc. The contents of this document or any part thereof should not be reproduced or disclosed to any third party without Power-One's express written consent.

REVISION TABLE

Document Revision	Date	Change Description
1.0	19-Nov-07	
1.1	12-Jan-09	
2.0	17-Mar-09	Certificate of Compliance added
2.1	26-Jun-09	Modified allowed cable section according to normative



SAVE THESE INSTRUCTIONS!



IMPORTANT SAFETY INSTRUCTIONS

IMPORTANT SAFETY INSTRUCTIONS

This manual contains important safety instructions that must be followed during the installation and startup of the equipment. To reduce the risk of electrical shock hazards and to ensure the equipment is safely installed prior to operation, special safety symbols are used in this manual to highlight potential safety hazards and provide important safety information. The symbols are:



WARNING: The paragraphs highlighted by this symbol contain processes and instructions that must be followed to avoid potential injury to personnel and equipment damage..



NOTE: The paragraphs highlighted by this symbol contain processes and instructions that must be followed to avoid potential equipment damage or negative results.

- The equipment is provided with several labels. Labels with a yellow background are related to safety issues.
- Read the labels and ensure that you understand them before performing equipment installation.
- The labels utilize the following symbols:

	Equipment grounding conductor (Main grounding protective earth, PE)
	Alternating Current (AC) value
	Direct Current (DC) value
	Phase
	Grounding (Earth)

USEFUL INFORMATION AND SAFETY STANDARDS

FOREWORD

- Installation of the Aurora inverter must be performed in full compliance with national and local standards and regulations.
- The Aurora inverter has no user-serviceable parts. For maintenance or service please contact Power-One Customer Service.
- Read the instructions contained in this manual and become familiar with the safety symbols in the relevant paragraphs before you install and operate the equipment.
- Connection to the distribution grid must be done only after receiving approval from the appropriate local distribution utility as required by national and state interconnection regulations, and must be done only by qualified personnel.
- Cover the photovoltaic panels with dark opaque sheets before they are connected. This helps prevent any hazardous high voltages from appearing at the connecting cable terminations.

GENERAL

- During inverter operation, parts may be powered, may lose proper insulation, and may move. In addition, some surfaces may become hot.
- Unauthorized removal of necessary protections, improper use, poor or incorrect installation, or improper operation may lead to serious injury to people and/or equipment damage.
- Transportation, handling, installation, startup, and maintenance must be performed by qualified and trained personnel (all accident prevention rules in force in the user's country must be observed!).
- Basic safety rules require using qualified and trained personnel that have the skills for assembly, startup, and operation of the product to perform such activities.

ASSEMBLY

- Devices should be assembled and cooled according to the specifications mentioned in their corresponding documents.
- In particular, during transport and handling, parts should not be bent and/or the insulation distances should not be changed. There should be no contact between electronic parts and connection terminals.
- Electrical parts must not be mechanically damaged or destroyed (this could cause potential health risks).

ELECTRICAL CONNECTION

- Always comply with all prevailing national accident-prevention regulations.
- Electrical connections such as conductor sections, fuses, PE connection, etc., must always be made in accordance with applicable regulations..

OPERATION


Systems with inverters should be provided with additional control and protective devices in compliance with the corresponding prevailing safety rules, such as those relating to the compliance with technical equipment, accident-prevention regulations, etc.

- Comply with all corresponding marks and symbols present on each device.
- Ensure that all covers and doors are closed during operation.
- Any calibration changes should be made using the operational software.
- Anytime that the inverter has been disconnected from the power grid, powered parts and electrical connections should not be touched as some capacitors could still be charged.

MAINTENANCE AND SERVICE

Contact Power-One Customer Service for maintenance and service needs.

SAVE ALL DOCUMENTS IN A SAFE PLACE!

 This document applies only to the PVI-3.0-OUTD-US, PVI-3.6-OUTD-US, PVI-4.2-OUTD-US, PVI-3.0-OUTD-S-US, PVI-3.6-OUTD-S-US, PVI-4.2-OUTD-S-US inverters.




Fig. 1 - Name Plate for PVI-4.2-OUTD-US

The name plate affixed to the inverter provides the following information:

- 1) Manufacturing Part Number
- 2) Model Number
- 3) Serial Number
- 4) Week/Year of Manufacture

CONTENTS

1	FOREWORD	10
1.1	PHOTOVOLTAIC ENERGY	10
2	SYSTEM DESCRIPTION	11
2.1	KEY ELEMENTS OF A PHOTOVOLTAIC SYSTEM: "STRINGS" AND "ARRAYS"	13
2.2	DATA TRANSMISSION AND CHECK.....	15
2.3	AURORA TECHNICAL DESCRIPTION	15
2.4	PROTECTIVE DEVICES	16
2.4.1	<i>Anti-Islanding</i>	16
2.4.2	<i>Panel Ground Fault</i>	16
2.4.3	<i>Additional Protective Devices</i>	17
3	INSTALLATION.....	18
3.1	PACKAGE INSPECTION.....	18
3.1.1	<i>Inspecting package contents</i>	19
3.2	SELECTING THE INSTALLATION LOCATION	19
3.3	BEFORE PERFORMING THE ELECTRICAL CONNECTIONS.....	24
3.3.1	<i>Switch Box ELECTRICAL CONNECTING and/or DISCONNECTING procedure</i>	26
3.3.2	<i>Removing the Front Cover and Accessing the Internal Terminal Block.</i> 28	
3.3.3	<i>Aurora Switch Box Description</i>	29
3.3.4	<i>AURORA Inverter Typical Electrical Installations</i>	34
3.3.5	<i>Possible Aurora DC Input Configuration</i>	35
3.3.5.1	<i>Aurora Inverter - Connection to a Single Photovoltaic Array</i>	36
3.3.5.2	<i>Parallel Connection of the Aurora DC inputs</i>	37
3.3.6	<i>Connection to the AC GRID</i>	40
3.3.7	<i>Connection of RS485 and Alarm contact</i>	42
3.4	DISCONNECTING THE AURORA INVERTER FROM THE DC SWITCH.....	46
3.4.1	<i>ELECTRICAL DISCONNECTION OF THE INVERTER FROM THE SWITCH BOX PROCEDURE</i>	46
3.5	CR2032 LITHIUM BATTERY REPLACEMENT	48
4	START-UP	49

5 MONITORING AND DATA TRANSMISSION..... 51

5.1	USER'S INTERFACE MODE	51
5.2	AVAILABLE DATA	54
5.2.1	<i>Real-time operational data</i>	54
5.2.2	<i>Internally logged data</i>	55
5.3	LED INDICATORS	56
5.4	MESSAGES AND ERROR CODES.....	59
5.5	LCD DISPLAY	62
5.5.1	<i>Connection of the system to the grid</i>	62
5.5.2	<i>Error messages</i>	63
5.5.3	<i>First phase - electric parameter check</i>	64
5.5.4	<i>Main menu</i>	67
5.5.5	<i>Statistics</i>	68
5.5.6	<i>Information</i>	68
5.5.6.1	Lifetime	68
5.5.6.2	Partial.....	69
5.5.6.3	Today	69
5.5.6.4	Last 7 days.....	69
5.5.6.5	Last Month	70
5.5.6.6	Last 30 Days	70
5.5.6.7	Last 365 Days	70
5.5.6.8	User period	70
5.5.7	<i>Settings</i>	72
5.5.7.1	Address	73
5.5.7.2	Display Set	73
5.5.7.3	Service	74
5.5.7.4	New Password	74
5.5.7.5	Cash	74
5.5.7.6	Time.....	74
5.5.7.7	Language	75
5.5.7.8	Start-up Voltage.....	75
5.5.7.9	Autotest	75
5.5.7.10	Alarm.....	76
5.5.7.11	Remote Control	77
5.5.7.12	UV Prot. time.....	78
5.5.7.13	MPPT scan	78

5.5.7.14	Scan Interval	78
5.5.8	<i>Info</i>	79
6	DATA CHECK AND COMMUNICATION.....	81
6.1	CONNECTION THROUGH RS-485 SERIAL PORT OR RJ12 CONNECTORS	81
6.1.1	<i>RS-485 serial port</i>	81
6.1.2	<i>RJ12 connectors</i>	84
6.1.3	<i>Daisy chain</i>	85
6.2	SERIAL CONNECTION WITH USB PORT	87
6.3	ALARM CONTACT CONNECTION	87
6.4	MEASUREMENT ACCURACY.....	88
7	TROUBLESHOOTING	89
8	TECHNICAL FEATURES.....	91
8.1	INPUT VALUES	91
8.2	OUTPUT VALUES	94
8.3	GRID PROTECTION CHARACTERISTICS	95
8.4	GENERAL CHARACTERISTICS	95
8.5	BACKFEED CURRENT	98
8.6	VOLTAGE AND FREQUENCY LIMITS	99
8.7	FAULT CURRENT	100
8.8	POWER DERATING	101

1 FOREWORD

This document contains a technical description of the Aurora Photovoltaic Inverter which provides the installer and user with the information required for its installation, operation, and use.

1.1 PHOTOVOLTAIC ENERGY

Industrialized countries (greater energy consumers) have been experimenting with energy-saving methods and the reduction of pollutant levels for many years thanks to the energy-conversion process. This may be possible through a shrewd and rational consumption of well-known resources, and also by looking for new forms of clean and non-exhaustible energy.

Regenerating sources of energy are fundamental to solve this problem. Under these circumstances, solar energy exploitation to generate electrical (photovoltaic) energy is becoming more and more important worldwide.

Photovoltaic energy, in any case, is of great advantage to the environment because the radiated energy we receive from the sun is transformed directly into electrical energy without any combustion process and without producing any pollution.

2 SYSTEM DESCRIPTION

The Aurora inverter feeds a power grid by using the power generated from photovoltaic panels. The photovoltaic panels transform sun-radiated energy into electrical energy in the form of direct current (DC) through a photovoltaic field (also known as a PV generator). In order to utilize this energy and feed it to the distribution grid, the energy needs to be converted into alternating current (AC). The Aurora inverter does this conversion, also known as DC to AC inversion, very efficiently using just static power electronic devices and without the need of rotating parts.

When used in parallel with the power grid, the alternating current generated by the inverter is directly fed to the domestic distribution circuit, which in turn is also connected to the public power distribution grid. The solar energy system can thus feed all the connected user electrical loads, such as lighting devices, household appliances, etc.

When the photovoltaic system is not generating sufficient energy, the power required to ensure proper operation of connected user loads is taken from the public power grid. While, if the produced energy exceeds load needs, it is directly fed to the grid, thus becoming available to other users' loads.

According to national and local standards and regulations, the user-produced energy can be sold to the grid or credited to the user against future consumption, thus reducing costs and providing what could even be significant savings.

Available versions

PVI-3.0-OUTD-US

PVI-3.6-OUTD-US

PVI-4.2-OUTD-US

PVI-3.0-OUTD-S-US

PVI-3.6-OUTD-S-US

PVI-4.2-OUTD-S-US

The S-US models are provided with an integrated 600V, 25A DC switch as shown on fig. 1a.




Fig.1a – Schema funzionale inverter con DC switch integrato.




Fig. 1b - Block diagram of inverters model without integrated DC switch

2.1 Key elements of a photovoltaic system: “STRINGS” and “ARRAYS”

The so-called STRINGS technology has been developed in order to reduce the installation costs of a photovoltaic system as much as possible. These costs are mainly related to the wiring operations on the inverter's DC side and the consequent distribution on the AC side.

A photovoltaic panel is composed of many photovoltaic cells assembled on the same mount. A String is composed of a certain number of panels electrically connected in series. An Array is composed of two or more strings electrically connected in parallel.

Larger photovoltaic systems may be implemented by using several arrays connected to one or more Aurora inverters.

The greater the number of panels in each string, the lower the cost and the less complex the wiring connections of the system.




Fig. 2 - Array Composition



WARNING: To avoid equipment damage, the string voltage must not exceed 600 Vdc for any reason.



NOTE: A minimum input voltage of 200 Vdc is required for the Aurora inverter to start the grid connection sequence. Once connected, the inverter will transfer the maximum available power for any DC input voltage value within a 90 Vdc to 580 Vdc range to the grid.

The total current of an array must also be within the capability limits of the inverter. For PVI-4.2 model, the limit is set at 16 Adc maximum for each input, while for PVI-3.0/3.6 models the limit is set at 10 Adc maximum for each input. The AURORA is capable of handling 2 separate arrays.

If the output of photovoltaic system exceeds the capacity of a single inverter, additional Aurora inverters can be added to the system; each inverter will be connected to an adequate section of the photovoltaic field on the DC side and to the grid on the AC side.

Each Aurora inverter will work independent of the others and will push the maximum power available from its own section of the photovoltaic panels to the grid. There are several factors and considerations to be taken into account when designing photovoltaic systems, such as the type of panels, available space, location, long-term target output, etc. The system configurator available on Power-One's web site at www.power-one.com may help in sizing a photovoltaic system.




Fig. 3 - Simplified Diagram of a Photovoltaic System

2.2 Data Transmission and Check

When more than one inverter is used, remote monitoring can be implemented through a sophisticated communication system based on an RS-485 serial interface, with a USB port to facilitate access during installation. An optional Aurora Easy-Control system is also available for remote monitoring via the Internet, analog modem, or GSM digital modem.

2.3 Aurora Technical Description

Figure 4 shows a block diagram of the Aurora inverter. The main elements are the input DC-DC converters (termed “boosters”) and the output inverter. Both the DC-DC converters and the output inverter operate at a high switching frequency to enable a compact design and relatively low weight.

This is a transformerless version of the Aurora, i.e. without galvanic insulation between input and output, which further increases conversion efficiency. On the other hand, the Aurora inverter is equipped with the necessary protective devices to ensure safe operation in compliance with applicable regulations without an insulation transformer. These protections are discussed in more detail in sections 2.4 through 2.4.3.




Fig. 4 - Aurora Inverter Block Diagram

The block diagram shows an Aurora PVI-3.0/3.6/4.2-OUTD-US with two independent input DC-DC converters; each converter is dedicated to a separate array with independent Maximum Power Point Tracking (MPPT) control. This means that the two arrays can be installed in different positions and orientations. Each array is controlled by an MPPT control circuit.

Thanks to its high efficiency and a generously-sized heat sink, the Aurora inverter provides maximum power operation in a broad range of ambient temperatures. The inverter is controlled by two independent Digital Signal Processors (DSPs) and one central microprocessor. This way, grid connection is controlled by two independent computers in full compliance with electrical power supply and safety regulations.

The Aurora inverter operating system communicates with the related parts to proceed to data processing. This process ensures optimal performance levels of the whole units, as well as a high efficiency under all solar radiation and load conditions, while always in full compliance with the applicable directives, standards, and regulations.

2.4 Protective Devices

2.4.1 *Anti-Islanding*

When the local power distribution grid fails due to a fault or when the equipment is shut down for maintenance operations, the Aurora inverter should be physically disconnected under safety conditions, so as to protect any personnel working on the grid, in full compliance with the applicable prevailing national standards and regulations. To avoid any possible islanding operation, the Aurora inverter is provided with an automatic disconnection protective system called Anti-Islanding.

The AURORA PVI-3.0/3.6/4.2-OUTD-US model is equipped with a state-of-the-art anti-islanding protection system certified to the following standards and regulations:

- CSA-C22.2 N.107.1-01 UL Std N.1741

2.4.2 *Panel Ground Fault*

The Aurora PVI-3.0/3.6/4.2 versions have been designed for use with panels with a floating connection (positive and negative terminals not connected to ground). A sophisticated ground protection circuit continually monitors the ground connection; when it detects a ground fault, this circuit shuts down the inverter and turns on a red LED on the front panel to indicate a ground fault condition. The Aurora inverter is equipped with a terminal for the system grounding conductor; see section 3.3.6 (steps 3 and 4) for more details.



NOTE: For more details of Aurora inverter shutdown or possible causes of malfunction, please refer to sections 5.3 and 5.4.

2.4.3 Additional Protective Devices

The Aurora inverter is equipped with additional protections to guarantee safe operation under any circumstances. The protections include:

- constant monitoring of grid voltage to ensure that voltage and frequency remain within the specified operational limits (in accordance with UL 1741 standard). For more detail see paragraph 8.6.
- automatic power limitation control based on internal temperature monitoring to avoid overheating (heat sink temperature $\leq 70^{\circ}\text{C}$ [158°F]).

Many control devices are fitted to Aurora, making its structure redundant, but at the same time ensuring a perfect and fully safe operation.

3 INSTALLATION



WARNING: The electrical installation of the Aurora inverter must be performed in accordance with the electrical standards prescribed by the local regulations and by the National Electric Code (ANSI/NFPA 70 standard).



WARNING: The connection of an Aurora inverter to the electrical distribution grid must be performed only after receiving authorization from the utility that operates the grid.

3.1 Package Inspection



NOTE: The distributor delivered your Aurora inverter to the carrier safely packaged and in perfect condition. Upon acceptance of the package, the carrier assumes responsibility for its safe delivery. In spite of careful handling, transportation damage to the package or its contents is always a possibility.

The customer is encouraged to perform the following checks:

- Inspect the shipping box for apparent damage, such as holes, cracking, or any other sign of possible damage to its contents.
- Describe any damage or shortage on the receiving documents and have the carrier sign his/her full name.
- Open the shipping box and inspect the contents for internal damage. While unpacking, be careful not to discard any equipment, parts, or manuals. If any damage is detected, call the delivering carrier to determine the appropriate action. Save all shipping material in the event that the carrier sends an inspector to verify damage!
- If the inspection reveals damage to the inverter, contact your supplier, or authorized distributor. They will determine if the equipment should be returned for repair. They will also provide instructions on how to get the equipment repaired.
- It is the customer's responsibility to file a claim with the carrier. Failure to file a claim with the carrier may void all warranty service rights for any damage.
- Save the Aurora inverter's original shipping package in the event that you should ever need to return the inverter for repair.

3.1.1 Inspecting package contents

Description	Quantity (No.)
Aurora Inverter	1
Bag containing: Nr.4 6.3x70 screws, nr.4 SX10 wall plugs, red cable AWG10, black cable AWG10, Torx20 wrench, nr.1 6x10 screw, nr.1 d.18 washer,	1
Installation and Operator's Manual	1
Certificate of warranty	1
CD-ROM with communication software	1

3.2 Selecting the installation location

Installation location should be selected based on the following considerations:

- Height from ground level should be such as to ensure that the display and status LEDs are easy to read.
- Select a well-ventilated location sheltered from direct sun radiation. Choose a location that allows unobstructed airflow around the inverter.
- Allow sufficient room around the inverter to enable easy installation and removal from the mounting surface.
- A door is provided on the front of the inverter to allow for hardware maintenance; and the USB port for software connection is on right side wall of the inverter (protected by a cover). Ensure free access to the right side; otherwise you will have to remove the inverter from its mounting surface.

The following figure shows the recommended minimum clearances around the inverter:




Fig. 5 - Installation Location - Minimum Clearances around the Aurora Inverter




Fig. 6 - Recommended Installation of Aurora Inverters



NOTE: Tilted mounting is permitted (see Fig. 7), but will reduce heat dissipation and may result in self-derating.



WARNING: The inverter surface may become hot to the touch during operation. To avoid burn injury, DO NOT touch the inverter surface during operation.




Fig. 7 - Tilted Mounting

The Aurora inverter should be mounted vertically as shown in figures.5, 6, 7, 8a, and 8b. Always follow the relative mounting instructions provided in this section.

Included in the shipping package is a mounting kit with 4 screws and 4 wall plugs provided for mounting the metal bracket to a concrete wall. The screws should be mounted in the 4 holes present in the bracket (shown as pos B in Fig. 8a).

If needed to ensure stability of the inverter, you can use 2 additional screws in the 2 holes shown as pos "A" in Fig. 8a.



WARNING: The bracket needs to be mounted vertically to the wall and the side with the hook (shown as pos C in Fig. 8b) should be mounted with the hook pointing upward as shown in the picture.



If the installation is done on a concrete wall, the wall plugs provided should be used, and the mounting holes in the wall should have a 10mm diameter and 75mm depth.



When the wall is made of a different material (other than concrete) the installation should be done using adequate mounting material. Power-One recommends always using stainless steel screws.

After the bracket is secured to the wall, install the inverter as shown in figure 8b.

The inverter should be hung onto the bracket using the hooks D and F that need to be well inserted into their counterparts C and E (D connects to C and F connects to E).

The inverter needs to be lifted up and then slid down over the hooks making sure that the connecting points in the bracket and in the back of the inverter engage properly.

After the inverter is hung onto the wall mounting, it needs to be secured using a M6x10 screw and the relative washer that will pass through the opening on the lower side of the inverter (shown as pos H in Fig. 8b) and into to the PEM fastener in position G of the bracket.





Fig. 8a - MP-01 –Wall Bracket

Fig. 8b - MP-02 – Wall Mounting



NOTE. It is recommended that you DO NOT expose the Aurora inverter to direct sun radiation or any other heat source, including heat generated by other Aurora inverters (see Fig. 6 "recommended installation").

When the ambient temperature rises above 50°C the inverter may self-derate the output power.

- Always make sure that the airflow is not blocked in any installations.

3.3 Before Performing the Electrical Connections



WARNING: Before performing any operation on the Switch Box power input, ALWAYS PERFORM the "Switch Box ELECTRICAL DISCONNECTION PROCEDURE" as explained in section 3.4.1 of this manual.



WARNING: The electrical connections must be connected only after the Aurora inverter is firmly mounted to the wall.



WARNING: The connection of the Aurora inverter to the electrical distribution grid must be performed by qualified and trained personnel and only after receiving authorization from the utility that operates the grid.



WARNING: For a step-by-step description of the correct procedure, please read - and closely follow - the instructions provided in this section (and its subsections) and all safety warnings. Not complying with the instructions that follow can lead to hazards and possible injury to personnel and/or equipment damage.



WARNING: All field wiring connected to signal circuits (WIND, ALARM, REM & RS485) must be UL/CSA certified, rated 600 V or higher, and must be additionally protected by means of a non-metallic conduit. Take care to provide means for securing all the above mentioned wiring away from both AC side and DC side field wiring. Moreover, AC side field wiring should be secured away from DC side field wiring.



WARNING: Always respect the nominal ratings of voltage and current defined in section 8 (Technical Features) when designing your system. Please observe these considerations in designing the photovoltaic system:

- Maximum array DC voltage input to each MPPT circuit: 600 Vdc under any condition.
- Maximum array DC current input to each MPPT circuit: 16A_{dc} under any condition for PVI-4.2 model, 10A_{dc} under any condition for PVI-3.0/3.6 models.



WARNING: The electrical installation of the Aurora inverter must be performed in accordance with the electrical standards prescribed by the local regulations and by the National Electric Code (ANSI/NFPA 70 standard).

On the AC output side an automatic magnetothermic switch should be inserted between the Aurora inverter and the distribution grid (see Fig. 9. - Electrical Connection Diagram).

On the DC input side a DC switch should be inserted when not integrated in the inverter. The -S models have an integrated DC switch 600V-25A



WARNING: To reduce the risk of fire, connect only to a circuit provided with 20A maximum branch circuit overcurrent protection in accordance with the National Electric Code (ANSI/NFPA 70)

3.3.1 *Switch Box ELECTRICAL CONNECTING and/or DISCONNECTING procedure*



WARNING: FOLLOW EACH STEP OF THIS PROCEDURE EXTREMELY CAREFULLY in order to avoid injury to personnel and/or equipment damage. The Aurora inverter works at high voltage levels that may be extremely dangerous if all precautions are not observed.



WARNING: THE FOLLOWING OPERATIONS MUST ALWAYS BE PERFORMED before accessing the power input of the Switch Box in order to avoid injury to personnel and/or damage to equipment.

STEP 1 If the inverter is connected to the AC Grid (Fig. 15- “Terminal Block for AC Connection”– pos. "1", "2" and "3"), DISCONNECT the inverter from the AC Grid by opening the switch indicated as Part “D” in Fig. 9-“Electrical Connection Diagram”. Disconnect the DC side switch (integrated in the –S models, or externally provided).

STEP 2 Carefully cover all the photovoltaic panels using appropriate cover or perform the grid CONNECTION and/or DISCONNECTION operation during night hours. Ensure that the no photovoltaic panel can provide energy during this operation.




Fig. 9 - Electrical Connection Diagram



WARNING: Always open the AC disconnect switch to disconnect the Aurora inverter from the Grid before opening the DC disconnect switch.



WARNING: To avoid the risk of electric shock from energy stored in capacitors, wait 5 minutes after disconnecting both AC and DC sides before opening the front panel.



WARNING: A requirement, when selecting the electrical cables, is to carefully evaluate the nominal operating voltage, the insulation rating, the max operating temperature, the current rating, and the flammability rating in accordance with the local safety standards.

When selecting the wire for the installation, the correct size needs to be selected in order to avoid efficiency losses. Refer to Table CN-01 (section 3.3.6) "AC Grid Connections" to select the cable size.

The electrical power and signals wiring from the inverter to the AC Grid and to the photovoltaic panel are connected through the Switch Box as described in Fig.11 SB-01 – "DC Switch Box Layout" –using the access windows in pos "A" for the power cables and the windows in pos "D" for the signal cables.

3.3.2 *Removing the Front Cover and Accessing the Internal Terminal Block.*



WARNING: Before performing the following instructions, ALWAYS perform the "ELECTRICAL DISCONNECTION OF THE INVERTER FROM THE SWITCH BOX PROCEDURE" located and described in section 3.4 1.

To remove the front cover, loosen the 4 screws shown in fig 10 pos "A", using the flathead screwdriver provided in the box with the inverter.




Fig.10 - Aurora Inverter with Front Panel and DC Switch

When the connection operations are completed, reinstall the front cover and tighten the 4 screws into the cover with at least 1.5Nm (13.2 in-lbs) torque to ensure proper waterproof sealing.

3.3.3 Aurora Switch Box Description




Fig. 11 - SB-01 – DC Switch Box Layout

Pos. Fig. SB-01	Description
A	DC and AC Power cable knockouts – SIZE: G1"
B	Silkscreen "ON" / "OFF"
C	DC Switch
D	Signal cable entries – SIZE: G1" ½



WARNING: The Switch Box disconnects the DC current from the photovoltaic panels when the switch is in “OFF” position (see the electrical schematics in Fig.11 SD-01 – Electrical Schematics DC Switch Box" and DOES NOT disconnect the AC line going to the Grid. To disconnect the inverter from the AC Grid, the AC switch (not included in the Switch Box) must be disconnected (see Fig. 9 - "Connection Diagram").



WARNING: Due to the high voltage present on the power cable in the Switch Box, ALWAYS disconnect the Switch Box from the DC power cables as described in the “Switch Box Connecting and/or Disconnecting procedure” (see section 3.3.2) prior to working on the cables.




Fig. 11 - SD-01 Switch Box DC Electrical Schematics




Fig. 11 SB-02 –Switch Box

POS	Details
A	Terminal Block AC OUT
B	DIN bars for accessories
C	Grid Standard Table
D	Main Ground \oplus - Max Wire Size = AWG# 4 (Refer to local code for minimum wire size)
E	Ground
F	DC IN Terminal Block
G	Cable Knockouts

Table SBD – Switch Box Internal Parts Summary.



WARNING: In order to thighten correctly the screw terminal of the switch box apply the AWG size, temperature and torque listed in the following table. The restrictions on minimum AWG value is due to cable gland. The restrictions on maximum AWG value is due to National Electric Code (ANSI/NFPA 70).

Models PVI-4.2(3.6)- OUTD-S-US	Wire Size	Temp	Torque	
	AWG (min-max)	°C	Nm	In- lbs
AC and GND field wiring terminals	4-10	90	2.26	20
	4-8	75		
DC field wiring terminals	4-10	90	2.26	20
	4-8	75		
Grounding Electrode	4-10	90	5.08	45
	4-8	75		

Models PVI-3.0- OUTD-S-US	Wire Size	Temp	Torque	
	AWG (min-max)	°C	Nm	In- lbs
AC and GND field wiring terminals	4-10	90	2.26	20
	4-8	75		
DC field wiring terminals	4-12	90	2.26	20
	4-10	75		
Grounding Electrode	4-10	90	5.08	45
	4-8	75		



WARNING: In order to thighten correctly the screw terminal of the inverter apply the AWG size, temperature and torque listed in the following table. The restrictions on minimum AWG value is due to cable gland. The restrictions on maximum AWG value is due to National Electric Code (ANSI/NFPA 70).

Models PVI-4.2(3.6)- OUTD-US	Wire Size	Temp	Torque	
	AWG (min-max)	°C	Nm	In- lbs
AC and GND field wiring terminals	6-10	90	1.69	15
	6-8	75		
DC field wiring terminals	6-10	90	1.69	15
	6-8	75		
Grounding Electrode	4-10	90	5.08	45
	4-8	75		

Models PVI-3.0- OUTD-US	Wire Size	Temp	Torque	
	AWG (min-max)	°C	Nm	In- lbs
AC and GND field wiring terminals	6-10	90	1.69	15
	6-8	75		
DC field wiring terminals	6-12	90	1.69	15
	6-10	75		
Grounding Electrode	4-10	90	5.08	45
	4-8	75		

3.3.4 *AURORA Inverter Typical Electrical Installations*



WARNING: Before performing any operation on the Switch Box power input, ALWAYS perform the "Switch Box CONNECTION and/or DISCONNECTION PROCEDURE" as explained in section 3.3.1 of this manual.



WARNING: THE INPUT CURRENT shall not exceed 16A_{dc} for each input channel (PVI-4.2) or 10A_{dc} (PVI3.0/3.6)



WARNING: Before performing the procedures described below, ALWAYS perform the "ELECTRICAL DISCONNECT PROCEDURE" as described in section 3.4.1 of this manual.

Step 1: Disconnect from the AC Grid by turning Off the "AC Bipolar Switch" – Part "D" in Fig. 9 "Electrical Connection Diagram".

Step 2: Remove the Switch Box cover and connect the DC cable to the terminal block at pos "F" in "Fig.11 SB-02 –Switch Box"; carefully check the correct polarity of the DC cable.

Step 3: Connect the AC cable by following the instructions in section 3.3.6, "Electrical Connection to the AC Grid". Refer to Table CN-01 "AC Grid Connection"

Step 4: Open the inverter cover (4 screws in pos "b" of fig. 10) and connect the signal cable (optional). Pass the cable inside the Switch Box through the input knockouts (see pos "D" fig.11 "SB-01 – DC Switch Box Layout"), and then inside the inverter through the cable gland placed in the upper side of the Switch Box; finally screw the cable to the appropriate terminal block inside the inverter.

Step 5: Remove the cover from the photovoltaic panel or wait for the sun to irradiate the panel



WARNING: Verify that the DC voltage in the Switch Box input (terminal block pos. "F" Fig.11 "SB-02") has the correct polarity and is within the operational range.

If the parameters are within the operating range defined in the specification, close and secure the inverter and the Switch Box covers and follow the instructions in section 4, "START-UP".

3.3.5 Possible Aurora DC Input Configuration



WARNING: Before performing any operation on the Switch Box power input, ALWAYS perform the "Switch Box CONNECTION and/or DISCONNECTION PROCEDURE" as explained in section 3.3.1 of this manual.



WARNING: Before performing the following instructions ALWAYS perform the "AURORA ELECTRICAL DISCONNECT PROCEDURE" in section 3.4.1 of this manual.

The Aurora inverter can be configured with an independent MPPT for each DC input channel or with the 2 input DC channel connected in parallel with one MPPT. If the inverter is configured with 2 independent MPPTs, the max current for each channel shall not exceed 16Adc for the PVI-4.2 model, or 10Adc for the PVI-3.0/3.6 models.



WARNING: THE INPUT CURRENT SHALL NEVER EXCEED 16Adc for the PVI-4.2 model or 10Adc for the PVI-3.0/3.6 models, for each channel (single contact in the terminal block "D.C. / \pm IN1 e \pm IN2") in the Switch Box.

After the DC connection is completed, follow the instructions in section 3.3.6, "ELECTRICAL CONNECTION TO THE AC GRID".

3.3.5.1 Aurora Inverter - Connection to a Single Photovoltaic Array

If the system has one single photovoltaic array and the current from it is less than 16A_{dc} for the PVI-4.2 model or 10A_{dc} for the PVI-3.0/3.6 models, and the power of the array is below the limit for the single channel (see table in 8.1 paragraph), then the array can be connected to one single input channel (IN1).



WARNING: Before performing the following instructions, ALWAYS perform the “AURORA ELECTRICAL DISCONNECT PROCEDURE” described in section 3.3.1 of this manual.

To avoid possible misreadings in the insulation parameters, we recommend using an electrical cable to short the 2 inputs of channel IN2 (shown in Fig. 12) that are not connected to the photovoltaic array.

The cover of the Aurora inverter needs to be removed (Ref. Fig. 14 / screw pos. "A") in order to gain access to the terminal block board.

After the cover is removed, short the pins marked as "- IN2" and "+ IN2" on the terminal block "DC INPUTS". To connect the 2 pins, use the cable provided with the unit as shown in Fig. 12.

After the above connections are completed, install the cover and tighten the screws with a 1.5Nm (13.2 in-lbs) torque and perform the START-UP procedure in section 4.




Fig. 12 - Short Circuit on IN2 Channel

3.3.5.2 Parallel Connection of the Aurora DC inputs



WARNING: Before performing the following instructions, ALWAYS perform the “AURORA ELECTRICAL DISCONNECT PROCEDURE” described in section 3.3.1 of this manual.



WARNING: When the current from the photovoltaic array exceeds 16Adc for the PVI-4.2 model, or 10Adc for the PVI-3.0/3.6 models, when the array power exceeds the limit for the single channel (see table in 8.1 paragraph), or when there is a consistent unbalance of the power between two arrays, it is necessary to parallel the 2 inputs.



WARNING: When the inverter is configured with parallel input the current to the 2 input terminals in the Switch Box—rif.: " ± IN1 " e "± IN2 " in fig. "13 / A – Parallel input connection " shall be equally distributed in such a way to limit to 16A_{dc} for the PVI-4.2 model, or 10A_{dc} for the PVI-3.0/3.6 models, the current for each terminal.

To parallel the 2 inputs, 2 AWG10 cables should be used to connect the terminal block –IN1 and –IN2, and +IN1 and +IN2 as shown in Fig. 13 (1 black and 1 red cable)




Fig. 13 - Parallel Connection

The switch “S1” should be placed to position “PAR” as shown in Fig 14 in order to configure the inverter in parallel mode.




Fig. 14 - Inverter Parallel Mode Configuration

After switching the Aurora inverter to parallel mode configuration, the front panel should be reinstalled (apply 13.2 in-lbs of torque to each of the 4 screws). After the front panel is secured, it is possible to begin the “START-UP “procedure. (see section 4).

3.3.6 Connection to the AC GRID



WARNING: Before performing the following instructions, ALWAYS perform the "AURORA ELECTRICAL DISCONNECT PROCEDURE" described in section 3.3.1 of this manual.

Step 1: Remove the Switch Box front panel (remove the 4 screws in pos "B" of Fig. 10).

Step 2: Lay down the cable between the Aurora inverter and the AC disconnect switch.

Step 3: Pass the AC cable inside Aurora through one of the cable glands present in the lower side of the Switch Box (see Fig. 11 - "SB-01 – "DC Switch Box Layout" – pos. "A")

Steps 4: Connect the 3 AC wires to the relative terminal block present inside the inverter. The AC wire connections should be done based on the type of AC Grid by following Table CN-01 –"AC Grid Connection ". The ground cable shall be connected to the terminal block indicated by the pointer of pos. "D" of Fig.11 SB-02 – "Switch Box"



WARNING: The photovoltaic grounding shall be installed per the requirements of sections 690.41 through 690.47 of the NEC, ANSI/NFPA 70 and it is responsibility of the installer.




Fig.15 - Terminal Block for AC Connection

Based on the local GRID standards, it is possible to select different connection types. The available configurations are shown in the following table (**Table CN-01 – "AC Grid Connections"**).




GRID STANDARD									
	208V~ 3PH - Δ			240V~ SPLIT-PHASE			277V~ 3PH - Y		
TERMINAL	1	2	3	1	2	3	1	2	3
WIRE	L1(*)	L2(*)	-	L1	L2	N	N	L 1(*)	-
AWG #	4 - 8								

Table CN-01 – AC Grid Connections



(*) IMPORTANT: If several Aurora inverters are installed in a three-phase AC GRID, it is recommended to distribute the inverters between the phases in order to reduce the power unbalances between the phases. Always refer to the local standards.

3.3.7 Connection of RS485 and Alarm contact



WARNING: Before performing the following instructions, ALWAYS perform the “AURORA ELECTRICAL DISCONNECT PROCEDURE” described in section 3.3.1 of this manual.

Step 1: Remove the Switch Box front panel (remove the 4 screws in pos “B” of Fig. 10). Remove also the cover of the Aurora inverter (Ref. Fig. 14 / screw pos. "A") in order to gain access to the terminal block board.

Step 2: Lay down the cables between the Aurora inverter and the outside passing trough the provided holes and cable glands on the Switch Box.

Step 2: Connect the communication and the alarm cables to the communication and alarm terminal block on the right side of the inverter. Follow the marking on the terminal block for appropriate connection.



WARNING: In order to separate correctly power cable from signal cables make sure to use the provided cable ties on the inverter and on the Switch Box. See fig. 15a, 15b for appropriate cabling.




Fig.15a – Complete cabling.




Fig. 15b – Complete cabling particular



WARNING: All the screws on the electrical input/output terminal block of the inverter should be tightened using 13 in/lbs torque.



(*) IMPORTANT: In case of inverter without the Switch Box, follow the same cabling approach for signal and communication cables as shown in fig. 15c




Fig.15b – Complete cabling, without Switch Box application

3.4 Disconnecting the AURORA Inverter from the DC Switch.

Use the procedure in paragraph 3.4.1 anytime that it is necessary to electrically disconnect the Aurora inverter from the DC Switch Box.

3.4.1 *ELECTRICAL DISCONNECTION OF THE INVERTER FROM THE SWITCH BOX PROCEDURE*



WARNING: The Aurora inverter operates at high voltages that can be extremely dangerous! **CAREFULLY FOLLOW EACH STEP OF THIS PROCEDURE** in order to avoid injury to personnel and/or equipment.damage.

WARNING: Always open the AC disconnect switch to disconnect the Aurora inverter from the Grid before opening the DC disconnect switch.

STEP 1: Disconnect the inverter from the AC Grid using the AC disconnect switch shown as " Part "D" in Fig. 9 – " Connection Diagram".

STEP 2: Wait about 5 minutes to allow the internal capacitors to discharge (verify that the LEDs on the front panel are OFF).

STEP 3: Disconnect the High Voltage DC power line coming from the photovoltaic arrays using the appropriate switch (switch "C" of the Switch Box shown in Fig. 11 - "SB-01 - DC Switch Box Layout"). Turn the switch to the OFF position as shown on the silk print shown in Fig. 11 "SB-01" and LOCK as shown in Fig. "SB-02 – DC Switch Box/Safety Lock". **This step completes the electrical disconnection of the inverter from the DC Switch Box.**



Fig. SB 02 – DC Switch Box – Safety Lock

After the ELECTRICAL DISCONNECTION OF THE INVERTER FROM THE SWITCH BOX PROCEDURE has been completed, remove the 2 front panels from the AURORA inverter as shown in section 3.3.2 "Access to the Internal Terminal Block".

Disconnect the DC cable from the inverter board (remove the 4 screws from the terminal block + and – IN1 and + and – IN2) (Fig. 13 - "Parallel Connection")

Disconnect the 3 AC cables ("1", "2" and "3") from the inverter pos "A", "B" and C in Fig. 15.

Place the DC cable inside the Switch Box; close the hole in the upper side of Switch Box using the following water-tight caps.

Quantity	Size	Alternative
2	G1"	M32
2	G1/2"	PG16, M20

Close the Switch Box cover using the 4 screws.

3.5 CR2032 Lithium Battery Replacement



WARNING: Before performing the following instructions, ALWAYS perform the “AURORA ELECTRICAL DISCONNECT PROCEDURE” described in section 3.4.1 of this manual.

Inside the Aurora inverter there is a CR2032 lithium battery. When this battery is at end-of-life, a message will be shown in the display informing that the battery needs to be replaced.

The battery is visible after removing the Aurora inverter's front panel. Refer to section 3.3.2 for the procedures to remove the front panel.

To insert the new battery into the battery holder the battery needs to be slid at a 30° angle as shown in Fig 16, and when pushed in on insertion it should seat into the correct position within the holder.





Fig.16 - Lithium Battery Replacement



WARNING: The replacement of this battery should be performed only by trained personnel.

After battery replacement is completed, reinstall and secure the front panel of the inverter and perform the START-UP procedure in section 4.

4 START-UP



WARNING: Do not place any items on the Aurora inverter during operation.



WARNING: Do not touch the heat sink when the inverter is operating, as some parts may be hot and cause burns.

The start-up procedure is as follows:

1) Set the external DC disconnect, if present, (for the photovoltaic panels) to ON

2) Set the external AC disconnect (for the grid) to ON.

There is no specific order for closing the two disconnects.



WARNING: This operation starts the connecting procedure for inverters. Do not open the inverter or the switch box.

3) Once both disconnects are closed, the inverter starts the grid connection sequence, unless the grid voltage and frequency parameters are found to be outside the operating range as per the UL 1741 standard. The check routine is indicated by the flashing green LED labelled POWER over the display.

The check routine may take from 30 seconds up to several minutes, depending on grid condition. Three screens are shown on the display during the check routing:

- “Measuring Riso...”, connection in progress with progress indication (Riso = insulating resistance)
- Grid voltage value and status compared to specified values (within/outside range).
- Grid frequency value and status compared to specified values (within/outside range).

4) When the connection sequence is completed, the Aurora inverter starts operating; proper operation is indicated by a warning sound and the green LED staying on steady. This means that sun radiation is sufficient to feed the grid.

5) If the grid check routine gives a negative result, the unit will repeat the procedure until all grid voltage and frequency parameters and grid configuration

are found to be within the specified range. During this process, the green LED will keep flashing.

5 MONITORING AND DATA TRANSMISSION

5.1 User's Interface Mode



WARNING: The RS-485 cable must provide at least 600V protection.



WARNING: The RS-485 cable must be UL/CSA certified wiring and must be additionally protected by means of a non-metallic conduit.

Normally, the Aurora inverter operates automatically and needs no particular supervision. When solar radiation is not enough to generate power for the grid (for instance, at night), the Aurora disconnects automatically and goes into standby mode.

The operating cycle is resumed automatically the moment when solar radiation becomes strong enough. This is indicated by the LEDs.

The Aurora inverter provides operational data in the following ways:

- LED indicators
- Operational data on the LCD display
- Data transmission on a dedicated serial RS-485 line. Data can be collected by a PC or a data logger equipped with an RS-485 port. If an RS-485 line is used, it may be convenient to use the Aurora RS-485/RS232 Serial Interface Converter model number PVI-RS232485. An optional Aurora Easy Control data logger is also available.
- Data transmission via USB cable. This type of connection is typically used when monitoring a single inverter and for maintenance purposes. To connect the USB cable, remove the waterproof plug at the bottom end of the inverter right wall (see Fig.17).



Fig.17 - USB Port




Fig. 18 - Data Transmission Options

5.2 Available Data

The Aurora inverter provides two types of data that can be collected using the Aurora Communicator interface software.

5.2.1 *Real-time operational data*

Real-time operational data can be transmitted on demand through the communication lines and are not stored by the inverter. The Aurora Communicator software (available on the installation CD) may be used to transmit data to a PC. Please check for the latest updated version at www.power-one.com).

The following data is available:

- Grid voltage
- Grid current
- Grid frequency
- Power transferred to the grid
- Voltage of photovoltaic array 1
- Current of photovoltaic array 1
- Voltage of photovoltaic array 2
- Current of photovoltaic array 2
- Heat sink temperature
- Serial number / Part number
- Manufacturing week
- Firmware revision code
- Daily energy
- Leakage current of the system
- Total energy
- Partial energy
- Mean grid voltage
- Insulation resistance
- Leakage current to ground
- Date, time

5.2.2 *Internally logged data*

Aurora stores internally the following data:

- Lifetime counter of grid connection time
- Lifetime counter of energy transferred to the grid
- Energy transferred to the grid every 10 seconds for the last 8640 periods of 10 seconds (which on average cover more than 2 days logged data)
- Partial counter of grid connection time (counter start time can be reset using the Aurora Communicator software)
- Partial counter of energy (uses the same start time as the partial time counter)
- Last 100 fault conditions with error code and time stamp
- Last 100 changes to grid connection parameters with parameter code and new value.

The first two types of data are displayed on the LCD and through the RS-485 interface, while all other data can be displayed only through the RS-485 interface.

5.3 LED indicators

There are three LEDs at the side of the display: the first LED from the left (POWER) indicates proper operation of the inverter, the LED in the middle (FAULT) indicates a fault condition, whereas the LED on the right (GFI) indicates a ground fault.

1. The green “Power” LED indicates that the Aurora inverter is operating correctly. This LED flashes upon start-up, during the grid check routine. If a correct grid voltage is detected and solar radiation is strong enough to start up the unit, the LED stays on steady. If not, the LED keeps flashing until solar radiation becomes strong enough to start up the inverter. In this condition, the display will read “ Waiting for sun...”
2. The yellow “FAULT” LED indicates that the Aurora inverter has detected a fault condition. A fault description will appear on the display.
3. The red “GFI” (ground fault) LED indicates that Aurora is detecting a ground fault in the DC side of the photovoltaic system . When this kind of fault is detected, the Aurora inverter immediately disconnects from the grid and the corresponding fault indication appears on the display. The inverter remains in this condition until the operator presses the ESC key to re-start the grid connection sequence. If the inverter does not reconnect to the grid, contact service to have the system checked.




Fig.19 - LED Location

LED indicator combinations and their meanings are listed in the following table.

KEY:



LED on



LED blinking



LED off



Any one of the above conditions

	LEDs Status	Operational Status	Remarks
1	green: <input checked="" type="checkbox"/> yellow: <input checked="" type="checkbox"/> red: <input checked="" type="checkbox"/>	Aurora self-disconnection during nighttime	Input voltage less than 90 Vdc at both inputs
2	green: <input type="checkbox"/> yellow: <input checked="" type="checkbox"/> red: <input checked="" type="checkbox"/>	Aurora initialization, settings loading, and waiting for grid check	It is in a transition status while operating conditions are being checked.
3	green: <input checked="" type="checkbox"/> yellow: <input checked="" type="checkbox"/> red: <input checked="" type="checkbox"/>	Aurora is powering the grid	Standard machine operation (search of max. power point or constant voltage).
4	green: <input type="checkbox"/> yellow: <input type="checkbox"/> red: <input checked="" type="checkbox"/>	System insulation device faulty	Ground leakage found
5	green: <input checked="" type="checkbox"/> yellow: <input checked="" type="checkbox"/> red: <input checked="" type="checkbox"/>	Defect – fault!!!	The fault can be inside or outside the inverter. See the alarm appearing on the LCD.
6	green: <input checked="" type="checkbox"/> yellow: <input type="checkbox"/> red: <input checked="" type="checkbox"/>	Installation phase: Aurora is disconnected from grid.	During installation, it refers to set-up of the address for RS-485 communication.
7	green: <input checked="" type="checkbox"/> yellow: <input checked="" type="checkbox"/> red: <input checked="" type="checkbox"/>	Grid disconnection	Indicates a missing grid condition.



NOTE: Inverter status is indicated by the corresponding LED turning to a steady on condition or flashing, and by a display message that provides a description of the existing operation or fault condition (see the following sections).

- | | | |
|----------|-------------------------------------|--|
| G | <input checked="" type="checkbox"/> | 1) Nighttime mode |
| Y | <input checked="" type="checkbox"/> | Aurora disconnected during nighttime; this occurs when input power is |
| R | <input checked="" type="checkbox"/> | too low to feed the inverter. |
| G | <input checked="" type="checkbox"/> | 2) Aurora initialization and grid check |
| Y | <input checked="" type="checkbox"/> | Initialization is in progress: input power sufficient to feed the inverter; |
| R | <input checked="" type="checkbox"/> | Aurora is verifying start-up conditions (for instance: input voltage value, insulation resistance value, etc.) and a grid check routine is launched. |
| G | <input checked="" type="checkbox"/> | 3) Aurora is feeding the grid |
| Y | <input checked="" type="checkbox"/> | After completing a set of electronics and safety auto-test routines, the inverter starts the grid connection process. |
| R | <input checked="" type="checkbox"/> | As mentioned above, during this stage Aurora automatically tracks and analyzes the maximum power point (MPPT) of the photovoltaic field. |
| G | <input type="checkbox"/> | 4) Ground insulation fault |
| Y | <input type="checkbox"/> | Aurora indicates that insulation resistance was found to be too low. |
| R | <input checked="" type="checkbox"/> | This may be due to an insulation fault in the connection between the photovoltaic field inputs and the ground. |



WARNING: Shock hazard! Do not attempt to correct this fault yourself. The instructions below have to be followed very carefully. In case you are not experienced or skilled enough to work safely on the system, contact a specialized technician.

What to do after an insulation defect has been found:

When the red LED turns on, try to reset the fault indication by pressing the multi-function ESC key at the side of the display. If the Aurora reconnects to the grid, the fault was due to a transient event (such as condensation and moisture getting into the panels). If this trouble occurs frequently, have the system inspected by a specialized technician.

If Aurora does not reconnect to the grid, open both the AC and DC disconnect switches to place the Aurora into a safe condition and contact an authorized service center to have the system repaired.

-
- | | | |
|----------|-------------------------------------|--|
| G | <input checked="" type="checkbox"/> | 5) Malfunction/Fault indication |
| Y | <input type="checkbox"/> | Every time the Aurora inverter's check system detects an operating malfunction or fault of the monitored system, the yellow LED comes on and a message showing the type of problem found appears on the LCD. |
| R | <input checked="" type="checkbox"/> | |
| G | <input checked="" type="checkbox"/> | 6) RS-485 address setup indication |
| Y | <input checked="" type="checkbox"/> | During installation, the yellow LED will keep flashing until the address is acknowledged. For further information about address entry, refer to section 5.5.7.1. |
| R | <input checked="" type="checkbox"/> | |
| G | <input checked="" type="checkbox"/> | 7) Grid disconnection |
| Y | <input type="checkbox"/> | If a grid failure event occurs while the system is in normal operation, the yellow LED turns on steady. |
| R | <input checked="" type="checkbox"/> | |

5.4 Messages and Error Codes

The system status is identified through message or error signals appearing on the LCD. The table that follows summarizes the two types of signals that can be displayed.

MESSAGES identify the current Aurora inverter status; so they do not relate to faults and nothing has to be done; messages disappears as soon as the system is back to normal operating conditions. See the W strings in the following table.

ALARMS identify a possible equipment fault or a fault of the connected parts. Alarm signals will disappear as soon as the causes are removed, except for ground insulation faults in the photovoltaic panels, which have to be corrected by qualified personnel. Usually, when an error signal appears, an action is needed. This action will be managed as much as possible by Aurora or, in case this is not possible, Aurora will supply all the necessary help information to the person who will have to perform the maintenance operations to fix the fault on the equipment or system. See the E strings in the following table.

Message	Warning	Error type	Description
Sun Low	W001	//	Input Voltage under threshold <i>Input voltage under threshold (when off)</i>
Input OC	//	E001	Input Overcurrent
Input UV	W002	//	Input Undervoltage
Input OV	//	E002	Input Overvoltage
Int.Error	//	E003	No parameters
Bulk OV	//	E004	Bulk Overvoltage
Int.Error	//	E005	Communication error
Out OC	//	E006	Output Overcurrent
Int.Error	//	E007	IGBT Sat
Sun Low	W011	//	Bulk Undervoltage
Int.Error	//	E009	Internal Error
Grid Fail	W003	//	Grid Fail Wrong grid parameters
Int.Error	//	E010	Bulk Low
Int.Error	//	E011	Ramp Fail
DC/DC Fail	//	E012	DcDc Error revealed by inverter DcDc fault detected by inverter
Wrong Mode	//	E013	Wrong Mode (Single instead of dual channel)
Over Temp.	//	E014	Overtemperature Internal temperature too high
Cap. Fault	//	E015	Bulk capacitor fail Bulk capacitor fault
Inv. Fail	//	E016	Inverter fail revealed by DcDc Inverter fault detected by DcDc
Int.Error	//	E017	Start Timeout
Ground F.	//	E018	I leak fai Leakage current fault I
Int.Error	//	E019	Ileak Sensor fail Leakage current fault
Int.Error	//	E020	DcDc relay fail DcDc relay fault
Int.Error	//	E021	Inverter relay fail Inverter relay fault
Int.Error	//	E022	Autotest Timeout
Int.Error	//	E023	Dc-Injection Error
Grid OV	W004	//	Output Overvoltage
Grid UV	W005	//	Output Undervoltage
Grid OF	W006	//	Output Overfrequency
Grid UF	W007	//	Output Underfrequency

Message	Warning	Error type	Description
Z Grid HI	W008	//	Z grid out of range Impedance outside range
Int.Error	//	E024	Unknown Error – Internal Error
-----	//	E025	Riso Low (Log Only) Low insulation resistance (Log only)
Int.Error	//	E026	Vref Error Wrong reference voltage (VRef)
Int.Error	//	E027	Vgrid Measures Fault Grid voltage (VGrid) misreading
Int.Error	//	E028	Fgrid Measures Fault Grid frequency (FGrid) misreading
Int.Error	//	E029	Zgrid Measures Fault Grid impedance (ZGrid) misreading
Int.Error	//	E030	Ileak Measures Fault Leak current (ILeak) misreading
Int.Error	//	E031	Wrong V Measure Voltage (V) misreading
Int.Error	//	E032	Wrong I Measure Current (I) misreading
Fan Fail	W010	//	Fan Fail (No disconnection) Fan faulty (Log Only)
Int.Error	//	E033	UnderTemperature Internal temperature
	//	E034	Interlock Fail (Not Used)
	//	E035	Remote Off Remote power-off
	//	E036	Vout Avg Average output voltage outside range
	W012	//	Clock Battery Low (No disconnection) Clock battery low (not operating)
	W013	//	Clock Failure (No disconnection) Clock faulty (not operating)

5.5 LCD Display


5.5.1 Connection of the system to the grid

The two-line Liquid Crystal Display is located on the front panel and shows:

- ✓ Inverter operating status and statistics;
- ✓ Service messages for the operator;
- ✓ Error messages and fault indications.

During regular operation, the display will cycle through available data. The display changes to a different screen every 5 seconds, or screens may be scrolled manually by pressing the UP (2nd key from display) and DOWN keys (3rd key from display).

1) These two screens are displayed upon inverter start-up:



2) The following screens may appear while waiting for the connection to be established:




- While the system checks for grid connection to be established (“Missing Grid”), the yellow LED next to the display turns on steady, while the green LED is flashing.
- When waiting for sun radiation (“Waiting Sun”), the green LED turns on steady.
- When the “Missing Grid” and “Waiting Sun” conditions are verified, the inverter is connected.

3) Time (seconds) to complete output voltage and frequency check.



4) Shows instant output voltage value and within/outside range status.



5) Shows instant output frequency value and within/outside range status.

Fgrid	50.17 Hz
In range	

6) If measured instant values of voltage (step 4) and frequency (step 5) are outside the allowed range, the following screens are shown alternately

- Next connections (screen 3)
- Vgrid (screen 4)
- Fgrid (screen 5)

7) Instant value of insulation resistance

Meas. Riso

5.5.2 Error messages

After the connection is established, the inverter runs a test cycle; if the wrong data is found, the cycle is interrupted and an error code is displayed. Please refer to the table in section 5.4 for error codes and their meanings.

Until the error is rectified, the following screens are alternately displayed:

ERROR Code

Type OUTD Part No.....

S/N
Firmware.....

Once the error has been removed, the inverter resets all functions in progress and re-starts the connection (Sect.5.5.1 Connection of the system to the grid, item 2).


- Missing Grid
- Waiting Sun

5.5.3 First phase - electric parameter check

A FEW POINTERS ON DISPLAY KEY OPERATION:

During normal operation, the display will cycle through available data. The display changes to a different screen every 5 seconds, or screens may be scrolled manually by pressing the UP (2nd key from display) and DOWN keys (3rd key from display).

Either way, pressing the ESC key (right next to the display) calls back the previous menu.



Auto-scroll is indicated by 2 arrows in the top left corner of the display (see Fig.20). To stop auto-scroll, press the ENTER key (4th key from display). A padlock will appear (see Fig.21).

1A) If the measurements taken previously (see section 5.5.1) are found to be correct, the system will proceed to the next checks. The 12 screens outlined below are shown alternately as listed in this section.

Type OUTD PN-----

2A) shows inverter serial number and firmware revision level.

S/N----- xxxxxx FW rel. C.0.1.1

3A)

E-tod	0	Wh
\$-tod	0.0	\$

E-tod: Daily energy output.

\$-tod: Daily energy savings. Value is expressed in the set currency.

4A)

E-tot	-----
E-par	0 KWh

E-tot: Lifetime energy output (since first installation)

E-par: Partial energy output (during selected period)

5A)

P-out	0 W
T-inv	- °C

P-out: Measured instant output power

The second line of the display shows the higher of two temperatures:

T-inv: inverter heat sink temperature or

T-boost: Heat sink temperature

6A)

Ppk	W
Ppk DayW

Ppk: Maximum peak power achieved since partial counter was activated

Ppk Day: Maximum peak power achieved during the day. Counter will reset when unit is powered off.

7A)

Vgrid	197 V
Vgrid Avg	0 V

Vgrid: Measured instant grid voltage

Vgrid Avg: Average grid voltage during the last 10 minutes of operation

8A)

Igrid	0.8 A
Fgrid	50.18 Hz

Igrid: Measured instant grid current

Fgrid: Measured instant grid frequency

9A)

Vin1	0 V
I in1	0.0 A

Vin1: Instant input voltage measured at channel 1 input

Iin1: Instant input current measured at channel 1 input

10A)

Vin2	0 V
I in2	0.0 A

Vin2: Instant input voltage measured at channel 2 input

Iin2: Instant input current measured at channel 2 input

Or:

Vin	0 V
I in	0.0 A

In a configuration with one input connected and a second input connected in parallel, this screen is shown instead of the 2 screens described in 9A) and 10A)..

11A)

Pin 1	0 W
Pin 2	0 W

Pin1: Measured instant input power of channel 1

Pin2: Measured instant input power of channel 2

Pin	0 W
------------	------------

In a configuration with one input connected and a second input connected in parallel, this screen is shown instead of the screen described in 11A)..

12A)

Riso	0.0 Mohm
Ileak	73 mA

Riso: Measured insulation resistance. Unlike the parameters discussed above, this is not an instant value but a one-of-a-kind measurement taken upon inverter start-up.

13A)

Inverter OK
Wed 17 May 11 23

If all items described above tested OK, the inverter shows a corresponding message in the display top line along with date and time. Clock malfunctioning or other non-function-related faults (meaning such faults that do not affect the inverter's ability to generate energy) are shown in the bottom line of the display in place of date and time.

The following error messages are provided:

- CLOCK FAIL indicates clock malfunction; contact service
- BATTERY LOW
- SET TIME, appears the first time the unit is powered up or after the battery has been replaced.
- FAN FAIL: contact service
- MEMORY FAIL: Data logging malfunction. Contact service.

5.5.4 Main menu

When the grid connection sequence described in section 5.5.3 and all electrical parameter checks are completed, other screens become available. These screens let you monitor inverter operation.

Pressing the ESC key (right next to display) gives access to 3 new screens:




A FEW POINTERS ON DISPLAY KEY OPERATION:

- Press the UP (2nd key from display) and DOWN keys (3rd key from display) to scroll through items.
- Press the ESC key (right next to display) to go back to the previous menu.
- Press ENTER (4th key from display) to open the selected submenu.

5.5.5 Statistics

Select the Statistics menu to display the following submenu:



5.5.6 Information

The display has 2 lines; use the keys at the side of the display to scroll through items or open the corresponding submenus as described in section 5.5.3. An arrow on the left side of the display highlights your current selection as shown in the following figure:



5.5.6.1 Lifetime

Select Lifetime to view the following information:

Time	h
E-tot	KWh
Val.	\$
CO2	lb

Time: Lifetime operation time

E-tot: Lifetime energy output

Val.: Money earned

CO2: CO2 saving compared to fossil fuels

5.5.6.2 Partial

Select Partial to view the following information:

Time	h
E-par	KWh
Ppeak	W
Val.	\$
CO2	lb

Time: Total operation time since counter was last reset *

E-par: Total energy output since counter was last reset *

PPeak: Maximum peak power measured since Partial counter was activated

Val.: Money earned since counter was last reset *

CO2: CO2 saving compared to fossil fuels since counter was last reset *

* Hold the ENTER key (4th key from display) depressed for over 3 seconds to reset all counters in this submenu. After 3 seconds, a warning sound is repeated 3 times.

5.5.6.3 Today

Select Today to view the following information:

E-tod	KWh
Ppeak	W
Val.	\$
CO2	lb

E-tod: Total energy output during the day

Ppeak: Peak power achieved during the day

Val: Money earned during the day

CO2: CO2 saving compared to fossil fuels during the day

5.5.6.4 Last 7 days

Select Last 7 days to view the following information:

E-7d	KWh
Val.	\$
CO2	lb

E-7d: Total energy output during the last 7 days

Val.: Money earned during the last 7 days

CO2: CO2 saving compared to fossil fuels during the last 7 days

5.5.6.5 Last Month

Select Last Month to view the following information:

E-mon	KWh
Val.	\$
CO2	lb

E-mon: Total energy output during the month

Val.: Money earned during the month

CO2: CO2 saving compared to fossil fuels during the month.

5.5.6.6 Last 30 Days

Select Last 30 Days to view the following information:

E-30d	KWh
Val.	\$
CO2	lb

E-30d: Total energy output during the last 30 days

Val.: Money earned during the last 30 days

CO2: CO2 saving compared to fossil fuels during the last 30 days

5.5.6.7 Last 365 Days

Select Last 365 Days to view the following information:

E-365d	KWh
Val.	\$
CO2	lb

E-365d: Total energy output during the last 365 days

Val.: Money earned during the last 365 days

CO2: CO2 saving compared to fossil fuels during the last 365 days

5.5.6.8 User period

User period

This feature measures energy saving during a period selected by the user.

Press ENTER from the "User period" screen to access the following submenu:

Start	23 June
End	28 August

Use the display keys to set the start and end date of the period as follows:

- Use ENTER to move from one field to the next (from left to right)
- Use ESC to go back to the previous field (from right to left)
- Press ESC repeatedly to go back to the previous menus as described in section 5.5.3

To set days:

- Press DOWN to scroll numbers backwards (from 31 to 1)
- Press UP to scroll numbers from 1 to 31

To set the month:

- Press DOWN to scroll months from December to January
- Press UP to scroll months from January to December

If set dates are inconsistent, the display alerts the user to the problem:

Data err

5.5.7 Settings


Select "Settings" from the Main menu (section 5.5.4) to display the first screen that refers to the password:



Default password is 0000. It can be changed using the keys on display:

- Use ENTER to move from one figure to the next (from left to right)
- Use ESC to go back to the previous figure (from right to left)
- Press ESC repeatedly to go back to the previous menus as described in section 5.5.3
- Press DOWN to scroll numbers backwards (from 9 to 0)
- Press UP to scroll numbers from 0 to 9

Type in the correct password and press ENTER to access all information of this section:




The display has 2 lines; use the keys at the side of the display to scroll through items or open the corresponding submenus as described in section 5.5.4 **A FEW POINTERS ON DISPLAY KEY OPERATION.**

An arrow on left side of the display highlights your current selection. When the chosen item is selected, press ENTER to open its submenu.

5.5.7.1 Address


This function is used to set addresses for communication of the single inverters connected in the system on an RS485 line. You can assign numbers from 2 to 250. Press UP and DOWN to scroll numbers.

If you do not want to manually set the address of each inverter, select the AUTO function and they will be distributed automatically.




5.5.7.2 Display Set

This function is used to set display features:



1) **Light**: display light setting:



- Use the MODE key to set display backlighting.

Select the Mode item with the arrow, and press ENTER to open the relevant submenu. shown on this screen:



ON: Light always on

OFF: Light always off

AUTO: Automatic light setting. It turns on every time a key is pressed and stays on for 30 seconds then gradually turns off.

- Use the INTENSITY key to set the intensity of backlighting from 0 to 9.

2) **Contrast:** display light contrast

Available display light tones go from 0 to 9.

Press UP and DOWN to scroll numbers and then press ENTER to confirm.

3) **Buzzer:** key tone setting

Selecting:

ON: key tone on

OFF: key tone off

5.5.7.3 Service

Only installing staff can gain access to this function, which is password-protected and dedicated code is supplied by Power-One.

5.5.7.4 New Password

This function is used to change the default password 0000.

To set your personal code, use the display keys as follows:

- Use ENTER to move from one digit to the next (from left to right)
- Use ESC to go back to the previous digit (from right to left)
- Press ESC repeatedly to go back to the previous menus as described in section 5.5.3
- Press DOWN to scroll numbers backwards (from 9 to 0)
- Press UP to scroll numbers from 0 to 9

5.5.7.5 Cash

This function is about energy output savings.

Name	\$
Val/KWh	00.50

Name: set desired currency, using keys as usual. Default currency is US Dollar.

Val/KWh: it indicates the cost of 1 KWh expressed in set currency. Default setting is 0.50 Euro.

5.5.7.6 Time

This function allows time and date setting.

Time	14:21
Date	17 May 2006


5.5.7.7 Language

It is possible to set the national language or English.




5.5.7.8 Start-up Voltage

Start-up voltage can be set according to the available photovoltaic system. Voltage range can be 120V to 350V. Default setting for Aurora is 200V. This parameter can be changed by means of the display keys.




5.5.7.9 Autotest

This is the Aurora inverter's internal test for checking correct operation of the protection and the grid interface device, as provided for by UL 1741 regulation.



Press ENTER to access all information of this section:



OV = Max. voltage

UV = Min. voltage

OF = Max. Frequency

UF = Min. Frequency

DC injection = Output current direct component. This component shall not be >0.5% with respect to inverter maximum rated current or the unit will switch off.

The display has 2 lines; use the keys at the side of the display to scroll through items or open the corresponding submenus.

An arrow on left side of the display highlights your current selection. When the chosen item is selected, press ENTER to open the submenu.

As soon as test is selected, the display shows

Test in progress

During the test the display gives test progress indication.

If the test passes, depending on selected item, the display shows:

Test	V= V
OK	T=ms

Test	F=.... Hz
OK	T=ms

Test	I=.... mA
OK	T=ms

V= measured voltage; T= time necessary to take the measurement

F= measured frequency; T= time necessary to take the measurement

I=measured current; T=time necessary to take the measurement

If the test fails, the following will be displayed:

Test	V= V
Fail	T=ms

Test	F=.... Hz
Fail	T=ms

Test	I=.... mA
Fail	T=ms

V= measured voltage; T= time necessary to take the measurement

F= measured frequency; T= time necessary to take the measurement

I=measured current; T=time necessary to take the measurement

5.5.7.10 Alarm

The inverter features an alarm function that opens or closes a relay contact, access can be gained through the front panel; the Alarm Contact Terminal Block is shown in Fig. 22. This relay contact can be used for instance to activate a siren or a visual alarm in case the inverter is disconnected from the grid (no energy output) or for any alarm event generated by the system.

This function can activate two alarm modes. Press ENTER to open the relevant submenu:

⇒ Production Fault

An arrow on left side of the display highlights your current selection. When the chosen item is selected, press ENTER to confirm activation of the chosen mode.

PRODUCTION: Relay is only activated when inverter is connected to the grid (contact closing across terminals “N.O.” and “C”)

FAULT: triggers relay activation (contact closing across terminals “N.O.” and “C”), only when an error signal occurs, i.e. when grid is disconnected, excluding Input Under Voltage.



Fig. 22 - Alarm Contacts Terminal Block

5.5.7.11 Remote Control

This function is used to disable the inverter manual switch-off. Operation is as follows:

- set to ENABLE to activate manual ON/OFF function
- set to DISABLE to disable manual ON/OFF function, so that Aurora operation will only depend on external solar radiation.

**Remote ON/OFF
Enable**

**Remote ON/OFF
Disable**

Manual ON and OFF input is read on inverter digital input. When set to OFF, the display will cycle through the following screens:

Remote OFF

**Waiting Rem.ON...
....to restart**

5.5.7.12 UV Prot. time

This function is used to set inverter connection time after input voltage drops below Under Voltage limit, set at 90V.

For example: if UV Prot. time is set at 60 seconds, and Vin voltage drops below 90V at 9.00, the inverter stays connected to the grid (at 0 power) up to 9.01.

Power-One sets this time at 60 seconds. The user can change this setting and set it from 1 second to 3600 seconds.

5.5.7.13 MPPT scan

This function is used to automatically detect input power max multiples.

MPPTscan En7Dis
Enable

5.5.7.14 Scan Interval


This function is used to set time interval for system max.multiple scan. Default setting is 15 minutes.


Scan Interval
15 min

5.5.8 Info

This menu is used to display all Aurora data:

- Part No. (part number)
- Serial No. – Wk – Yr (serial number, week, year)
- Fw rel (firmware release level)





6 DATA CHECK AND COMMUNICATION

6.1 Connection through RS-485 serial port or RJ12 connectors

6.1.1 RS-485 serial port

RS-485 serial port uses a three-wire cable: two wires are for signals and the third one is for a ground connection. The cables are routed through the hole located on the bottom of the Switch box which is blanked with waterproof plugs (see Fig. 23 -23a). Supplied cable gland must be installed in the hole selected for use.



Fig.23 - Hole for cables necessary for RS-485 port connection or wiring for RJ12 connectors connection.



Fig.23a - Holes for cables necessary for RS-485 port connection or wiring for RJ12 connector connection (without the switch box).

After passing through cable gland, cables are connected inside of the unit to RS-485 terminal blocks that can be reached by removing the front cover. Refer to paragraph 3.3.2 for details on correct front cover removal and reassembly procedure. Refer to paragraph 3.3.7 for details on correct cabling.

- Signal wires must be connected to +T/R and -T/R terminals
- Ground wire must be connected to RTN terminal





Fig. 24 - Terminals for connection to RS-485 serial line and S2 switch

6.1.2 RJ12 connectors

As an alternative to RS485 serial connection, whether using single units or a daisy chain, inverter connection can be performed by means of RJ12 connectors (see Fig. 24).

Wiring is again routed through the holes located at the bottom of the Inverter which are blanked with waterproof plugs (see Fig. 23). Input wiring passes through one hole and is to be assembled to one of the RJ12 connectors; it does not matter whether it is no. 1 or no. 2 since signals are the same considering that they are connected in parallel. Output wiring goes out from the other RJ12 connector through the other hole and extends to the next unit.

RJ12 connectors			
	Pin #	Signal Name	Description
 <p>RJ12 (SF8C)</p>	1		Not Used
	2	+TR	+ Data Line Required for RS485 communication.
	3	+R	Remote OFF Required or Remote OFF control (see section 5.5.7.11 for details).
	4	-TR	- Data Line Required for RS485 communication.
	5		Not Used
	6	RTN	Signal Return Common reference for logical signals.

6.1.3 Daisy chain

The RS-485 terminal block or RJ12 connectors can be used to connect a single Aurora inverter or multiple Aurora inverters connected in a daisy chain. The maximum number of inverters that can be connected in a daisy chain is 248. The recommended maximum length of this chain is 1200 meters.

In a case where multiple inverters are connected in a daisy chain, it is necessary to assign an address to each unit. Refer to paragraph 5.5.7.1 for instructions on how to set addresses.

In addition, the last inverter of the chain must have line termination contact active (S2 switch -120Ω TERM set to ON). See Fig. 24.

Any Aurora device is supplied with default address two (2) and with the S1 DIP switch in the OFF position.

In order to ensure optimum communication on the RS485 line, Power-One recommends connecting the PVI-RS232485 adapter to a location between the first unit of the daisy chain and the computer. See Fig. 25 for further details.

Other equivalent devices available on the market can also be used but Power-One does not assure correct connection operation since their equipment has never been tested with these equivalent devices.

Please note that these other equivalent commercial devices could require an external termination impedance, which is not necessary for Aurora PVI-232485.

Figure 25 shows you how to connect multiple units into a daisy chain configuration.




Fig. 25 - Daisy Chain Multiple Connection



NOTE: When using an RS-485 link there can be up to 248 inverters connected on the same link. Choose any address between 2 and 248.



NOTE: When using the RS-485 link, in case one or more inverters are added later to the system, please remember to switch the DIP-switch of the former last inverter of the system back to the OFF position

6.2 Serial connection with USB port

Serial connection through use of the inverter's USB port allows connection of a single inverter to a personal computer equipped with a USB 2.0 interface and dedicated software supplied by Power-One. The PC-inverter connection cable is a standard USB 2.0 cable, 5 meters long, with terminals of the A and B type. Just remove the waterproof plug located on Aurora's side to make the connection (see Fig. 26).



Fig.26 - USB Connection

6.3 Alarm contact connection

Three connections are provided to drive an external alarm: a common contact, a normally open contact and a normally closed contact. To cable alarm contact use a three-wire or two-wire cable. The cables are routed through the hole located on the bottom of the Switch box which is blanked with waterproof plugs (see Fig. 23 -23a). Refer to 3.3.7 for correct cabling procedure.

6.4 Measurement Accuracy



Every measure should consider possible errors.

The following tables show for each reading:

- measurement units;
- capacity;
- resolution

	Name of measured variable	Unit of Measure	Resolution		Maximum error percentage
			Display	Value	
Input voltage PV N°1	VP1	Vdc	1V	600mV	2%
Input voltage PV N°2	VP2	Vdc	1V	600mV	2%
Input current PV N°1	IP1	Adc	0.1A	25mA	2%
Input current PV N°2	IP2	Adc	0.1A	25mA	2%
Output power PV N°1	Pin1	W	1 W	10 W	2%
Output power PV N°2	Pin2	W	1 W	10 W	2%
Output voltage	Vout	V	1V	-	2%
Output current	Iout	A	0.1A	-	2%
Output power	Pout	W	1 W	-	2%
Frequency	Freq	Hz	0.01	0.01	0.1%
Accumulated energy	Energy	Wh	1Wh		4%
Time counter	Lifetime	hh:mm:ss	1s		0.2
Partial time counter	Partial Time	hh:mm:ss	1s		0.2

7 TROUBLESHOOTING

Aurora inverters comply with standards set for grid-tied operation, safety, and electromagnetic compatibility.

Before being delivered, the product has been successfully subjected to several tests to check: operation, protective devices, performance, and durability.

All these tests, together with the system ensuring Power-One quality, guarantee Aurora optimal operation.

In case of any possible malfunction of the inverter, solve problems as follows:

- ✓ Work under safe conditions, as stated in section 3.3 and following, check that connections between the Aurora, photovoltaic field, and power distribution grid have been made correctly.
- ✓ Carefully observe which LED is blinking and read the signal appearing on the display; then, following the instructions given in chapters 5.3, 5.4, and 5.5, try to identify the type of fault found.

If the malfunction cannot be removed by following these instructions, contact the service center or the installer (see following page).

Before contacting the service center, keep the following information handy:

INFO Aurora



NOTE: Information to be found directly on LCD

- ✓ Aurora model?
 - ✓ Serial number?
 - ✓ Week of production?
 - ✓ LED flashing?
 - ✓ Light blinking or steady?
 - ✓ Signal displayed?
-
- ✓ Malfunction short description?
 - ✓ Can malfunction be reproduced?
 - ✓ If so, how?
 - ✓ Does malfunction appear cyclically?
 - ✓ If so, how frequently?
 - ✓ Is malfunction present from installation?
 - ✓ If so, has it worsened?
 - ✓ Description of the atmospheric conditions when the malfunction appeared.

INFO on the Photovoltaic Field

- ✓ Make and model of photovoltaic panels
- ✓ System structure:
 - array max. voltage and current values
 - number of strings for the array
 - number of panels for each string

8 TECHNICAL FEATURES

8.1 Input Values



WARNING: the Photovoltaic field and system wiring must be configured in such a way that the PV input voltage is less than the maximum upper limit independently from the type, the number, and the operating conditions of the chosen photovoltaic panels.

As panel voltage also depends on working temperature, the number of panels per string shall be chosen according to the min. ambient temperature expected in that special area (see table A).



WARNING: The Aurora Inverter is provided with a linear output power derating depending on the input voltage, starting from 530 Vdc (100% output power) to 580 Vdc (0% output power)



WARNING: The open circuit voltage of the photovoltaic panels is affected by the ambient temperature (the open circuit voltage increases as the temperature decreases). You have to make sure that the minimum temperature estimated for the installation doesn't cause the panels to exceed the maximum upper limit of 600Vdc. As an example, the following table shows for typical panels of 36, 48, and 72 cells the maximum voltage of each panel as a function of the temperature (assuming a nominal open circuit voltage of 0.6Vdc per cell at 25°C and a temperature coefficient of -0.0023V/°C). The table shows, therefore, the maximum number of panels that can be connected in series as a function of the minimum temperature at which the system will operate. Consult the panel manufacturer for the correct temperature coefficient of Voc, before calculating the maximum voltage of the photovoltaic array.

Minimum Panel Temp.[°C]	36 Cells Panels		48 Cells Panels		72 Cells Panels	
	Panel voltage	Max number of panels	Panel voltage	Panel voltage	Max number of panels	Panel voltage
25	21.6	27	28.8	20	43.2	13
20	22.0	27	29.4	20	44.0	13
15	22.4	26	29.9	20	44.9	13
10	22.8	26	30.5	19	45.7	13
5	23.3	25	31.0	19	46.5	12
0	23.7	25	31.6	19	47.3	12
-5	24.1	24	32.1	18	48.2	12
-10	24.5	24	32.7	18	49.0	12
-15	24.9	24	33.2	18	49.8	12
-20	25.3	23	33.8	17	50.7	11
-25	25.7	23	34.3	17	51.5	11

Table A

Description	Value PVI-3-0-OUTD	Value PVI-3.6-OUTD	Value PVI-4.2-OUTD
Max. recommended DC power input	3500 W	4150 W	4820 W
Nominal DC power input	3120 W	3750 W	4380 W
Nominal input voltage	360 Vdc	360 Vdc	360 Vdc
Max. absolute input voltage	600 Vdc	600 Vdc	600 Vdc
Input voltage, MPPT operating range	from 90 Vdc to 580 Vdc	from 90 Vdc to 580 Vdc	from 90 Vdc to 580 Vdc
Input voltage, MPPT operating range at full power	from 200 Vdc to 530 Vdc	from 200 Vdc to 530 Vdc @Vgrid = 277 Vac or 240 Vac ; from 220 Vdc to 530 Vdc @Vgrid = 208 Vac	from 200 Vdc to 530 Vdc @Vgrid = 277 Vac or 240 Vac ; from 220 Vdc to 530 Vdc @Vgrid = 208 Vac
Max. short circuit current (of each array)	12.5 Adc	20 Adc	20 Adc
Max. operating input current (of each array)	10 Adc	16 Adc	16 Adc
Input backfeed current	Negligible	Negligible	Negligible
Max. input power (of each channel)	2000 W	3000 W	3000 W
PV Ground fault protection	Ground fault detector and interruption provided		

Input channels configuration	Two independent MPPT channels with shared negative poles or Two channels in parallel
------------------------------	---

(1) The total input power shall not exceed the max. Recommended DC power



NOTE: If the input current supplied by the photovoltaic field connected to the inverter is above the max. value and the input voltage is within the allowed range, the inverter will not be damaged.

8.2 Output values

Description	Value PVI-3.0-OUTD	Value PVI-3.6-OUTD	Value PVI-4.2-OUTD
Nominal output power	3000 W	3600 W	4200 W
Grid voltage, maximum range	183 to 304 Vac	183 to 304 Vac	183 to 304 Vac
Grid voltage, nominal	277V single phase or 240V split phase (default) or 208V single phase (setting required)	277V single phase or 240V split phase (default) or 208V single phase (setting required)	277V single phase or 240V split phase (default) or 208V single phase (setting required)
Grid voltage, operating range as per UL 1741 regulation	88% to 110% of nominal voltage (211 to 264Vac for V=240Vac)	88% to 110% of nominal voltage (211 to 264Vac for V=240Vac)	88% to 110% of nominal voltage (211 to 264Vac for V=240Vac)
Grid frequency, nominal	60 Hz	60 Hz	60 Hz
Grid frequency, operating range as per UL 1741 regulation	59.3 to 60.5 Hz	59.3 to 60.5 Hz	59.3 to 60.5 Hz
Nominal output	10.8/12.5/14.4	13/15/17	15.1/17.5/19.9

current	Arms	Arms	Arms
Max. output current	12/14.5/14.5 Arms	16/17.2/17.2 Arms	20/20/20 Arms
Output over current protection	15/20/20 Arms	20/25/25 Arms	25/25/25 Arms

8.3 Grid protection characteristics

Anti islanding protection	Complies with: - UL 1741 standard.
---------------------------	---------------------------------------

8.4 General characteristics

Description	Value PVI-3-0-OUTD	Value PVI-3.6-OUTD	Value PVI-4.2-OUTD
Maximum efficiency	96.8% (96 EURO)	96.8% (96 EURO)	96.8% (96 EURO)
Internal consumption during stand-by	< 8 W	< 8 W	< 8 W
Internal consumption during nighttime	< 2 W	< 2 W	< 2 W
Operating ambient temperature	-25°C to +60°C (*)	-25°C to +60°C (*)	-25°C to +60°C (*)
Casing protection rating	IP65 / Nema 4X	IP65 / Nema 4X	IP65 / Nema 4X
Audible noise with internal fan on	< 50 dbA @ 1m	< 50 dbA @ 1m	< 50 dbA @ 1m
Size (height x width x depth):	787 x 325 x 208mm	787 x 325 x 208mm	787 x 325 x 208mm

Weight	18 kg	18 kg	18 kg
Relative Humidity	0 – 100 % condensation point	0 – 100 % condensation point	0 – 100 % condensation point

(* Full power guaranteed up to $T_{amb} = 45^{\circ}\text{C}$ for PVI-4.2, 55°C for PVI-3.6 and 55°C for PVI-3.0 (as far as unit is not exposed to direct sun radiation))




Fig. 27 – Efficiency curve PVI-3.0-OUTD




Fig. 28 – Efficiency curve PVI-3.6-OUTD




Fig. 29 – Efficiency curve PVI-4.2-OUTD

8.5 Input Source Backfeed Current

PVI-4.2(3.6, 3.0)-OUTD-x-US Grid Tied Inverters are provided with two separate and consecutive power stages:

- Booster Stage (DC-DC converter) connected to DC Input Terminals.
- Inverter Stage (DC-AC converter) connected to AC Output Grid Terminals.

The Booster Stage is provided with forward diodes that allows the current (power) flow only from DC Input terminals towards Inverter (Output) Stage.

In case of any fault on Inverter Stage, these diodes avoid any back-feed current phenomena towards input terminals.

In case of fault of the forward diode, the corresponding booster MOSfet goes immediately and permanently in short circuit state and it avoids any current propagation from output to input terminals.

Abnormal Fault tests conducted during UL1741 qualification show also that these type of faults produce the opening of internal grid disconnect relays and cause the external AC CB protection devices to trip, preventing any power flow from the grid.

In conclusion for PVI-4.2(3.6, 3.0)-OUTD-x-US-y models it is not possible to have any single fault responsible of Input source back-feed current flow. For these models the Back-feed current into DC Source is negligible.

8.6 Voltage and frequency limits

The UL1741 requires, for voltage and frequency, the following limits for utility interaction:

Condition	Simulated utility source		Maximum time (sec) at 60 Hz ^a before cessation of current to the simulated utility
	Voltage (V)	Frequency (Hz)	
A	$< 0.50 V_{nor}^b$	Rated (60 Hz)	0.16
B	$0.50 V_{nor}^b \leq V < 0.88 V_{nor}$	Rated (60 Hz)	2
C	$1.10 V_{nor}^b < V < 1.20V_{nor}$	Rated (60 Hz)	1
D	$1.20V_{nor} \leq V$	Rated (60 Hz)	0.16
E	Rated	$f > \text{rated} + 0.5^c$	0.16
F	Rated	$f < \text{rated} - 0.7^c$	0.16

^a When a utility frequency other than 60 Hz is used for the test, the maximum number of cycles it takes to cease to export power to the simulated utility shall not exceed the number of cycles a utility frequency of 60 Hz takes regardless of the time the inverter takes to cease to export power to the simulated utility.

^b V is the nominal output voltage rating.

^c The rate of change in frequency shall be less than 0.5 Hz per second.

The PVI-4.2(3.6,3.0)-OUTD-x-US voltage and frequency limits are listed in the following table:

Condition	Trip Limits		Trip Times (sec)
	Voltage (V)	Frequency (Hz)	
A	$< 0.55 V_{nor}^b$	Rated (60 Hz)	0.12
B	$0.55 V_{nor}^b \leq V < 0.90 V_{nor}$	Rated (60 Hz)	1.8
C	$1.08 V_{nor}^b < V < \max(1.18 V_{nor}; 310Vac)$	Rated (60 Hz)	0.9
D	$\max(1.18 V_{nor}; 310Vac) V_{nor} \leq V$	Rated (60 Hz)	0.12
E	Rated	$f > \text{rated} + 0.42$	0.12
F	Rated	$f < \text{rated} - 0.62$	0.12
Accuracy	2%	0.02Hz	0.033
^b V is the nominal output voltage rating.			

8.7 Fault Current

The output current in case of fault (short circuit between lines or between line and neutral) has been measured according to UL1741 requirements. The following tables shows the corresponding current and duration:

Models	Output Voltage	Fault Current RMS (A)	Duration (mSec) 3 cycles	Fault Current PK (A)	Total Duration (mSec)
PVI-4.2-OUTD Series	208	13.5	49.92	122.4	119.0
	240	14.7	49.92	164.4	120.9
	277	12.3	49.92	165.9	123.2
PVI-3.6-OUTD Series	208	12.2	49.92	93.9	124.4
	240	12.5	49.92	136.5	120.2
	277	11.3	49.92	164.6	116.3

PVI-3.0- OUTD Series	208	11.7	49.92	162.0	121.8
	240	10.6	49.92	139.7	118.9
	277	8.6	49.98	92.2	116.5

8.8 Power Derating

In order to ensure inverter operation under safe conditions both from the temperature and electrical point of view, the unit automatically decreases power input in the distribution grid.

Power derating can occur in two cases:

Power reduction due to environmental conditions

Power reduction and temperature at which it occurs depend on many operating parameters other than ambient temperature, such as input voltage, grid voltage, and power available from the photovoltaic panels. The Aurora inverter can thus decrease power output during certain periods of the day according to these parameters.

In any case, the inverter ensures top power up to 40°C ambient temperature, when it is not directly exposed to the sun.

Power reduction due to input voltage

The graph in Fig. 27 shows automatic power output derating when input or output voltage is too high or too low.




Fig. 30




Fig. 31

Necessary conditions for power derating due to environmental conditions and to input voltage can occur at the same time, but in this instance power derating will always consider the lowest value detected.



Certificate of Compliance

Certificate: 2096477

Master Contract: 173688

Project: 2096477

Date Issued: 2009/03/06

Issued to: Power-One, Inc

740 Calle Plano
Camarillo, CA 93012
USA

Attention: Mr. Gianfranco Iannuzzi

The products listed below are eligible to bear the CSA Mark shown with adjacent indicators 'C' and 'US' for Canada and US or with adjacent indicator 'US' for US only or without either indicator for Canada only.



Issued by: Rob Hempstock, AScT.

Authorized by: Lindsay Clark, Product Group Manager

A handwritten signature in black ink, likely belonging to Lindsay Clark.

PRODUCTS

CLASS 5311 09 - POWER SUPPLIES - Distributed Generation Power Systems Equipment
CLASS 5311 89 - POWER SUPPLIES - Distributed Generation - Power Systems Equipment
- Certified to U.S. Standards

Utility Interactive Inverter, Models PVI-4.2-OUTD-US, PVI-3.6-OUTD-US, PVI-3.0-OUTD-US, PVI-4.2-OUTD-S-US, PVI-3.6-OUTD-S-US, PVI-3.0-OUTD-S-US, PVI-4.2-OUTD-US-W, PVI-3.6-OUTD-US-W and PVI-3.0-OUTD-US-W; provided with two DC input channels, permanently connected.



Certificate: 2096477

Master Contract: 173688

Project: 2096477

Date Issued: 2009/03/06

Notes:

For details related to ratings, reference should be made to the CSA Certification Record, Appendix 1 or the Descriptive Report.

APPLICABLE REQUIREMENTS

CAN/CSA-C22.2 No. 0-M91 - General Requirements - Canadian Electrical Code - Part II

CAN/CSA-C22.2 No. 0.4-04 - Bonding of Electrical Equipment

CSA-C22.2 No.107.1-01 - General Use Power Supplies

UL Std No. 1741-First Edition - Inverters, Converters, Controllers and Interconnection System Equipment for Use With Distributed Energy Resources (Including Revisions through and including November 7, 2005)



Supplement to Certificate of Compliance

Certificate: 2096477

Master Contract: 173688

The products listed, including the latest revision described below, are eligible to be marked in accordance with the referenced Certificate.

Product Certification History

Project	Date	Description
2096477	2009/03/06	Utility Interactive Inverters, PVI-4.2, PVI-3.6 and PVI-3.0 Series. (C/US)



Letter of Attestation

Document: 2096477 **Master Contract:** 173688
Project: 2096477 **Date Issued:** March 6, 2009
Issued to: Power-One Italy S.p.A
Via San Giorgio 642
Terranuova Bracciolini, Arezzo 52028
Italy

Attention: Mr. Gianfranco Iannuzzi

*CSA International hereby confirms that it has completed an evaluation of
Utility Interactive Inverters,*

**Models PVI-4.2-OUTD-US, PVI-3.6-OUTD-US, PVI-3.0-OUTD-US,
PVI-4.2-OUTD-S-US, PVI-3.6-OUTD-S-US, PVI-3.0-OUTD-S-US,
PVI-4.2-OUTD-US-W, PVI-3.6-OUTD-US-W and PVI-3.0-OUTD-US-W.**

*CSA International hereby attests that the products identified above and described in CSA report
2096477 complies with the following standards/tests, to the extent applicable:*

The testing of the subject inverters were completed according to the following sections of the test protocol entitled "Performance Test Protocol for Evaluating Inverters Used in Grid-Connected Photovoltaic Systems" prepared by "Sandia National Laboratories, Endecon Engineering, BEW Engineering, and Institute for Sustainable Technology", dated October 14, 2004 as modified by the "CEC Guideline for the use of the Performance Test Protocol for Evaluating Inverters Used in Grid-Connected Photovoltaic Systems - (draft for immediate use)" prepared by KEMA-Xenergy, and BEW Engineering, dated March 1, 2005 with deviations according to the requirements of the California Energy Commission New Solar Homes Partnership Guidebook 2nd edition (CEC-300-2007-008-CMF), Appendix 3, Section B – "Inverters":

- **Maximum Continuous Power**
- **Conversion Efficiency**
- **Tare Losses**

Notes:

1. Models PVI-4.2-OUTD-S-US, PVI-3.6-OUTD-S-US, and PVI-3.0-OUTD-S-US were tested as being representative of the series. Each model is available in 208V ac, 240V ac, and 277V ac outputs and each output voltage was tested.
2. Models PVI-4.2-OUTD-S-US, PVI-3.6-OUTD-S-US, and PVI-3.0-OUTD-S-US are identical to models PVI-4.2-OUTD-US, PVI-3.6-OUTD-US, and PVI-3.0-OUTD-US, except for an integrated switch box.
3. Inverter Models PVI-4.2-OUTD-US-W, PVI-3.6-OUTD-US-W and PVI-3.0-OUTD-US-W are intended for operation with Regulated Wind Generated supplies only; these inverters are intended to receive an input supply from a wind generator interface module (which converts AC voltage from a wind generator into a DC voltage).



Certificate: 2096477
Project: 2096477

Master Contract: 173688
Date: March 6, 2009

4. Inverter Models PVI-4.2-OUTD-US-W, PVI-3.6-OUTD-US-W and PVI-3.0-OUTD-US-W are identical in construction to models PVI-4.2-OUTD-US, PVI-3.6-OUTD-US, and PVI-3.0-OUTD-US.
5. For summary of test results refer to Attachment 1 (Model PVI-4.2-OUTD-S-US, 14 pages), Attachment 2 (Model PVI-3.6-OUTD-S-US, 14pages) and Attachment 3 (Model PVI-3.0-OUTD-S-US, 14 pages).

Issued by:

A handwritten signature in black ink, appearing to read 'Rob Hempstock'.

Rob Hempstock, AScT.

THIS LETTER OF ATTESTATION DOES NOT AUTHORIZE THE USE OF THE CSA MARK ON THE SUBJECT PRODUCTS.
QUOTATIONS FROM THE TEST REPORT OR THE USE OF THE NAME OF THE CANADIAN STANDARDS ASSOCIATION AND CSA INTERNATIONAL OR ITS REGISTERED TRADEMARK, IN ANY WAY, IS NOT PERMITTED WITHOUT PRIOR WRITTEN CONSENT OF THE CANADIAN STANDARDS ASSOCIATION OR CSA INTERNATIONAL.

superiorsolar
hot water | solar power | pool heating

Unit 2/10
Enterprise Close
West Gosford
2250
tel : 4323 9050