

GRAPHIC DISPLAY


The display updates the values of your PV plant every 5 seconds.

Tapping on the lower lid:

- Activates the background illumination
- Switching through the energy values of the past 16 feeding operations to the daily energy values of the past 16 days
- Switches to the next text line
- 2 taps in quick succession: the inverter successively shows the firmware version, the serial number of the description of the inverter, the *Bluetooth* NetID, and the specified country standard and display language.

Graphical display of the inverter energy

Disturbance: contact installer



Current power

Daily energy

Total energy generated since the inverter was installed

Display of Enabled Functions

Text line for displaying an event